














<div><div>KOCOM</div><div>SMART CAMERA</div><div>KC-K6 (3MP~FHD)</div></div> <div><div><div>Wi-Fi Connection</div><div>App Control</div></div><div>※ Please read this manual carefully before use and keep it for future reference.</div></div> <div></div>	<div><div>Basic Parameters</div><div>Product Name : Smart Camera Pixel : 3MP Video Compression : H.264 H.265 High Profile Image Enhancement : Digital Wide Dynamic 3D Noise Reduction Local Storage : MicroTF card Wireless Encryption : WEP/WPA/WPA2 Encryption Power Input : 5V 1A(Max) Total Power Consumption : 5W (Max) WirelessStandard : 2.4G 802.11 b/g/n Support Platform : Android/iOS</div><div><div>Component Description:</div><div>Reset Button : Long press "reset" hole 5sec, reset success.  It is recommended to insert 8-128GB high-speed Micro TF card, otherwise it will not be able to store, view historical video and support important functions such as firmware upgrading.  Packing list : Smart Camera × 1, Manual × 1, USB Power Cord × 1, Power Adapter × 1, Screw Accessories Package × 1</div></div></div>	<div><div>Install APP</div><div>Download APP: scan the QR code below to download and install. Register and login: open the " KOCOM Home " APP to register and login according to the prompts.</div><div><div>iOS / Android</div></div></div>	<div><div>User Guide</div><div>1. Make sure Wi-Fi is available and connected to the Internet, Connect the camera to the power, then system startup completed. Choose "WiFi Smart Camera"</div><div></div></div>	<div><div>2. Hold the reset key for more than 5 seconds, and the indicator flashes into the automatic network connection mode. Enter the WiFi password according to the prompt, and click to confirm.</div><div></div></div>	<div><div>3. QR code will prompt on your screen and you need to scan it with the Smart Camera. (the camera is about 20-30 cm away from the mobile phone lens). Then click "hear the prompt sound."</div><div></div></div>	<div><div>4. Then you can click directly to the device interface to see the monitoring situation.</div><div></div></div>	<div><div><div>Easy, Convenient, Safe Home</div></div></div>
---	--	---	--	---	--	---	---

<div><div>KOCOM</div><div>스마트 카메라</div><div>KC-K6 (3MP~FHD)</div></div> <div><div><div>Wi-Fi Connection</div><div>App Control</div></div><div>※ 사용 전에 꼭 설명서를 주의 깊게 읽고 내용에 알맞을 수 있도록 지켜주세요.</div></div> <div></div>	<div><div>제품 사양</div><div>상품명 : Smart Camera 픽셀 : 3MP 비디오 압축 : H.264 H.265 High Profile 이미지 개선 : Digital Wide Dynamic 3D Noise Reduction 로컬 저장소 : MicroTF card 무선 암호화 : WEP/WPA/WPA2 암호화 전력 입력 : 5V 1A (Max) 총 전력 소비량 : 5W(Max) 무선 표준 : WiFi 2.4G 802.11 b/g/n 지원 플랫폼 : Android/iOS</div><div><div>구성 요소</div><div>메모리 카드 (옵션) : 8~128GB 고속 마이크로 TF 카드를 사용해 주십시오. 저품질 또는 불량 메모리 카드는 저장 기능과 비디오 보기 및 원격에 일그러짐과 같은 중요 기능을 지원 할 수 없습니다.  포장 목록 : 스마트 카메라 × 1, 매뉴얼 × 1, USB 전원 코드 × 1, 전원 어댑터 × 1, 설치 스크류 액세서리 패키지 × 1</div></div></div>	<div><div>앱 다운로드</div><div>APP 다운로드 : 아래 QR 코드를 스캔하여 다운로드하고 설치하십시오. 등록 및 로그인 : "KOCOM Home" APP을 열어 메시지에 따라 등록 및 로그인합니다.</div><div><div>iOS / Android</div></div></div>	<div><div>제품 사용 안내</div><div>1. Wi-Fi를 사용할 수 있고 인터넷에 연결되어 있는지 확인합니다. 카메라를 전원에 연결합니다. 시스템 시작이 완료되면 "WiFi 스마트 카메라" 선택합니다.</div><div></div></div>	<div><div>2. 처음 전원이 켜지면, 자동으로 자동 네트워크 연결모드로 진입됩니다. (네트워크 연결 모드로 연결할 경우, 제품 후면의 리셋버튼을 5초 이상 길게 누르시기 바랍니다.)</div><div></div></div>	<div><div>3. QR 코드가 화면에 표시되면 스마트폰으로 QR코드를 스캔합니다. (카메라는 휴대폰 렌즈로부터 약 20~30cm 떨어져 있습니다.)</div><div></div></div>	<div><div>4. 기기 등록이 완료되면, 카메라가 촬영하는 화면을 앱을 통하여 실시간으로 확인할 수 있습니다.</div><div></div></div>	<div><div>제품보증서</div><div>KOCOM 해당 제품의 무상 보증 기간은 구매일로부터 1년입니다. 제품의 결함으로 확인된 제품에 대해서는 소비자 보호법에 의한 소비자 보상 기준에 따라 보상하여 드립니다. 품질보증기간 중 소비자터 과실이 아닌 제품의 하자로 인한 경우에만 교환이나 무상 A/S 가 가능합니다. 소비자의 취급 부주의 또는 불일보증 기간이 경과한 제품은 무상 책임을 지지 않습니다. 제품 사용시 문제가 발생할 경우 절대 분해하지 마시고, 아래 고객지원센터로 문의주시기 바랍니다. 제품을 임의로 분해하시면 보증기간 내에도 무상 A/S를 받으실 수 없습니다.</div><div><div>"안전한 제품 사용을 위해 본 사용설명서의 내용을 잘 숙지해주시고 이 외에 다른 방법으로 제품 사용시 발생하는 문제에 대해서는 책임을 지지 않습니다.</div><div><div>A/S 및 고객센터</div><div>제품에 이상이 있거나 문의사항이 있으신 경우 본 제품의 구입 판매점 혹은 코콤 고객센터로 연락바랍니다.</div></div></div><div><div>1577-0051 kocomas@kocom.co.kr</div><div>김포사옥 (10136) 경기도 김포시 고촌읍 아라곡로 22</div></div></div>
---	--	--	---	---	---	--	---